



5 EASY STEPS ON HOW TO PROGRAM YOUR LCD

- 1) Hold the "+" and "-" buttons down for 3 seconds.
- 2) Use the "+" and "-" to change the options.
- 3) Use the "i" button to select the settings to change.
- 4) Hold the "+" and "-" buttons to exit the menu
- 5) Turn the LCD off and back on, to save the settings.

VIEW OUR NEW VIDEO OF THE OVERVIEW & INTRODUCTION OF THE E-BIKEKIT LCD DISPLAY

[CLICK HERE TO
WATCH THE VIDEO](#)

